envisioneer™

BIM FOR EVERYONE

Version 12

Training Guide

Modeling • Landscaping • Rendering • Animation • Estimating • Documentation

Copyright © 2016 Cadsoft Corporation

TABLE OF CONTENTS

PHASE A: SETTINGS AND INTERFACE A-1

Starting the Program A-1
Starting a New Project A-1
Getting to Know the Interface A-2
Using the Master Catalog A-3
Using the Commander A-3
Design Guidelines A-4
Settings A-5

PHASE B: MODELING B-1

Drawing Walls B-2
Adding Interior Walls B-4
Inserting a Fireplace B-12
Inserting Doors B-13
Inserting Windows B-16
Inserting Openings B-19
Inserting a Roof B-20
Viewing the Model B-23
Raising and Lowering Elements B-28
Switching Back to 2D Plan View B-28
Using the View Filter B-29

PHASE C: INTERIORS C-1

Customizing Floors C-1
Inserting Ceilings C-3
Creating a Kitchen with the Kitchen Builder Wizard C-4
Inserting Cabinets C-7
Inserting Plumbing Fixtures C-8

PHASE D: STRUCTURAL ELEMENTS D-1

Creating a Foundation Plan D-1
Inserting Beams D-6
Inserting Columns D-9
Creating a New 3D View D-10
Inserting Pad Footings D-11
Inserting a Structural Floor system D-12

PHASE E: WORKING DRAWINGS E-1

Viewing Elevations E-1
Creating a Section E-2
Adding Dimensions to Your Plan E-3
Adding Text E-5
Working in Worksheet View E-8
Inserting Views E-9
Creating More Working Drawings E-10
Inserting a Title Block E-12
Quick Tip: Saving Time with Templates E-13
Inserting Elevations and Sections E-13
Generating a Project Estimate E-20

PHASE F: LANDSCAPE DESIGN F-1

Inserting a Site Boundary F-1
Inserting a Hill F-2
Inserting a Slope F-3

PHASE G: RENDERING AND ANIMATION G-1

Creating a 3D RealView™ Rendering G-1
Presentation Mode G-5
Animations G-6

PHASE H: QUESTION AND ANSWER PERIOD H-1